

Tripod Mount Field Upgrade

Copyright 2025 Michael Aiello N2HTT, all rights reserved. Rev A 1-March-2025

This field upgrade kit contains a new bottom bracket with a 1/4-20 threaded tripod mount installed.

Hardware Supplied

2 Button head screws M3 x 10mm,
stainless steel



Your hardware packet will contain one spare screw, in case the cat knocks one off the workbench and it rolls under the bookshelf. **Do not be alarmed that you have left over hardware!**

Tools Needed (not included.)

2 mm hex key

1. Start by locating the 2 M4 x 6mm flat head screws that hold the metal plate to the bottom of the rig.



2. Remove the screws but leave the metal plate in place. **Save these screws in a safe place, you will need them should you ever decide to remove the tripod mount.**



3. Line up the tripod mount with the holes in the bottom of the rig, and place the 2 M3 x 10mm screws in the holes.



4. Tighten the two screws securely, but do not over tighten.



5. Attach your tripod to the 1/4-20 threaded insert in the mount. Tighten securely, but do not over tighten.



6. Enjoy your new tripod mount! Check the mounting screws and the tripod attachment periodically to insure that everything remains secure.

